Pin Usage	
Available (shared)	RESET
Available (shared)	3.3V
Available (shared)	5V
Available (shared)	GND
Available (shared)	GND
Available (shared)	Vin
Available(unconnected)	A0
Available(unconnected)	A1
Available(unconnected)	A2
Available(unconnected)	A3
SDA (UNO)	A4
SCL (UNO)	A5



Pin Usage	
SCL	SCL
SDA	SDA
AREF	Available(unconnected)
GND	Available (shared)
13	Routed to Servo Header 3 (Leonardo)
12	Available(unconnected)
11	Routed to Servo Header 11
10	Routed to Servo Header 10
9	Routed to Servo Header 9
8	Available(unconnected)
7	Available(unconnected)
6	Routed to Servo Header 6
5	Routed to Servo Header 5
4	Available(unconnected)
3	Routed to Servo Header 3 (UNO)
2	Available(unconnected)
1	Available(unconnected)
0	Available(unconnected)

Copyright © 2015 OpenElectrons.com